

Forbo FloorCare method

Colorex Plus AS and EC do not carry any factory coating. Depending on your own requirements and preferences, a polymer sealer can be applied after installation for later ease of maintenance. If this is the case, follow the manufacturer's instructions on how to apply, correctly maintain and strip & renew the sealer. The following care and maintenance advice applies to Colorex plus AS and EC without any coating, as they are delivered.

colorex[®] plus AS / colorex[®] plus EC

Cleaning after installation



- Vacuum the floor to remove dust and dirt
- Scrub with water and neutral cleaner, low speed rotary machine and green scrub pad
- Pick up dirty water with water vac
- Allow the floor to dry
- Dry polish with a low speed rotary machine with red buffing pad to restore the original smooth surface of the floor.



- For Colorex plus EC conductive floors, any coating, sealer or maintenance products you use can affect the conductive performance of the floor. Always pay attention that any product is duly certified for use on conductive floors.

Regular cleaning for small and low traffic areas



- Wipe with impregnated single use towels or vacuum the floor
- Remove spots with a damp mop



Periodic cleaning for larger and high traffic areas



- Spray clean with a low speed rotary machine and a red buffing pad
- A scrubber dryer with red pads can be used instead



Occasional maintenance



- Scrub with water and neutral cleaner, low speed rotary machine and green scrub pad
- Pick up dirty water with water vac
- Allow the floor to dry
- Dry polish with a low speed rotary machine with red buffing pad to restore the original smooth surface of the floor.



- For large areas, a scrubber dryer with green scrub pads can be used instead.
- Additional dry polishing with red buffing pads will still be required.

The structured surface of Colorex plus ST requires a different and more simple set of techniques for its care and maintenance.

colorex[®] plus ST

Cleaning after installation



- Vacuum the floor with a brush attachment to remove dust and loose dirt



- Scrub with water and neutral cleaner, rotary machine and scrubbing brush
- Pick up dirty water with water vac

Regular cleaning



- Vacuum the floor with a brush attachment
- Remove spots with a damp mop



Periodic cleaning and occasional maintenance



- Scrub with water and neutral cleaner, rotary machine and scrubbing brush
- Pick up dirty water with water vac



- A scrubber dryer with scrubbing brushes can be used instead